







































## Compatible remote controls














<i>Company</i>	<i>Frequency</i>	<i>Models</i>	<i>Photo</i>	<i>Supported by:</i>
<b>ADYX</b>	433.920	ALIZE EM2C, ALIZE EM4C		Multi, Four
<b>AETERNA</b>	433.920	TX433 1,2,4 buttons		Multi, Four
<b>ALLMATIC</b>	306.000	ASMX2, ASMX4		Multi
	433.920	AEMX1, AEMX2, AEMX4		Multi, Four
		EUROPE AUTO ARMY1, ARMY2, ARMY4		Multi, Four
		MX1, MX2, MX4		Multi, Four
<b>ALLISTER</b>	318.000	9931-318, 9931T-318		Multi
<b>ALLSTAR</b>	288.000	111025 Allister Pulsar Quickcode		Multi
		9921T-288, 9921MT, 9921TK, 9922T-288, 9923T-288, 9931-288, 9931T-288, 9931MT, 9931TK, 9931TK6, 8831T-288, 8832T-288, 8833T-288, 8821T-288, 8822T-288, 8823T-288, 8832TK		Multi
		8833OCS-288		Multi
	318.000	9921T-318, 9921MT, 9921TK, 9922T-318, 9923T-318, 9931-318, 9931T-318, 9931MT, 9931TK, 9931TK6, 8831T-318, 8832T-318, 8833T-318, 8821T-318, 8822T-318, 8823T-318, 8832TK		Multi
		110995 Allister Pulsar Quickcode		Multi
		8830OCS-318		Multi
<b>ALLTRONIK</b>	433.920	S429_1, S429_2, S429_4, S429_M  Be sure that your remote operates at 433.92MHz!	 	Multi Rev.3, Four Rev.3
		S425		Multi Rev.3, Four Rev.3
<b>ANSONIC</b>	433.920	SA 434-1E, SA434-2E, SA434-3E, SA434-4E		Multi, Four
		SA 434-1MINI, SA434-2MINI, SA 434-2Midi		Multi, Four

	868.350	SA 868-1E, SA 868-2E, SA868-3E, SA868-4E		Multi
		SA 868-1mini/M, SA 868-2mini/M (dip switch version)		Multi
<b>APERTO</b>	433.920	CPS1, CPS2, CPS4		Multi, Four
<b>APRIMATIC</b>	305.000	TS1, TS2		Multi
<b>AUTELCO</b>	286-306	TX300T		Multi
<b>AVIDSEN</b>	433.920	100601 micromark MM23164		Multi, Four
		104505		Multi, Four
		100951, 100955, 100550, 100400		Multi, Four
<b>B&amp;D BnD BD</b>	433.920	062170/4333EBD, 062171, 4333A		Multi, Four
		062162		Multi, Four
		PTX4 059120 / 059116		Multi, Four
<b>BANDY</b>	433.920			Multi, Four
<b>BELFOX</b>	433.920	DHS433-1, DHS433-2, DHS433-4, dip switch version		Multi, Four
		DHS 433,92 (7733), dip switch version		Multi, Four
	868.350	DHS 868,3, dipswitch version		Multi
		HS 868-20		Multi
<b>BENINCA'</b>	306.000	LOT1A, LOT2A, LOT4A		Multi
		LOTX1A, LOTX2A, LOTX4A		Multi
		LO.TX2PS		Multi
	433.920	LOT1W, LOT2W, LOT4W		Multi, Four
		LOT2WMS		Multi, Four



		T2WK, T4WK		Multi, Four
		LOTX1W, LOTX2W, LOTX4W		Multi, Four
		TO.GO2WP, TO.GO4WP, TO.GO2WK, TO.GO4WK		Multi, Four
<b>BESIDE</b>	433.920	BEZAP		Multi, Four
		HIT		Multi, Four
<b>BETA ELETTRONICA</b>	315.000	BETALARM 6500		Multi
	330.000	BETALARM 5500		Multi
<b>BFT</b>	306.000	RCS		Multi R3
	315.000	VTM1, VTM2, VTM4		Multi
	418.000	GT01, GT02, GT04		Multi
	433.920	TE01, TE02 ( TEO1, TEO2 )		Multi, Four
		TE04 ( TEO4 )		Multi, Four
<b>BREDA</b>	433.920	Breda TOP432SA	Like CAME TOP432SA, blue	Multi, Four
<b>CAME</b>	315.000	Came T312M, T314M		Multi
	433.920	Came T432, T434, TOP432A, TOP434A, TOP432, TOP432NA, TOP434NA, TAM432, TAM434, TAM438		Multi, Four
		Came TOP432M, TOP434M		Multi, Four
		Came TAM432SA		Multi, Four
		Came TOP432SA		Multi, Four
		Came TOP432NA, TOP434NA		Multi, Four
		Came TWIN2, TWIN4		Multi, Four
		CAME TOP-432EV, TOP-434EV		Multi, Four

	868.350	CAME TOP862NA, Came TOP864NA		Multi
<b>CARDIN</b>	300.000	S300		Multi
	310.000	S301, S302		Multi
	433.920	S476 TX2, S476TX4		Multi, Four
<b>CARPER</b>	300.000	C300, C310, C318, C318T		Multi
	310.000			
	318.000			
<b>CASALI GENIUS</b>	330.000			Multi
	433.920	Genius 433 2, Genius 433 3, JA400 TM433, JA401 TM433		Multi, Four
<b>CASIT</b>	306.000	ERTS92B, ERTS92T		Multi
	433.920	ERTS92B, ERTS92T		Multi, Four
		ERTS20DB, ERTS20DQ		Multi, Four
		ERTS476D, ERTS476Q		Multi, Four
		TXS1, TXS2, TXS3, TXS4, TXS6 ERTS97B, ERTS97T		Multi, Four
<b>CELINSA</b>	433.920	S10 1, S10 2, SAW1, SAW2		Multi, Four
<b>CENTURION</b>	433.920	CLASSIC, SMART, SMART2		Multi, Four
<b>CHAMBERLAIN LIFTMASTER MOTORLIFT SEARS CRAFTSMAN</b>	300.000	Chamberlain 300MC (multicode)		Multi
	315.000	333LM		Multi
		360LM, 362LM, 363LM		Multi
	390.000	50CB, 53CB, 750CB, 753CB, 50LM, 53LM, 61LM, 62LM, 63LM, 139.53100, 139.53110, 139.53200, 139.53210		Multi
		54CB, 756CB, 54LM, 64LM, 859CB		Multi
		850CB, 853CB, 959CB, 81LM, 82LM, 83LM, 84LM, 99LM		Multi

		33LM		Multi
	418.000	4180, 4182, 4183		Multi
		4185		Multi
		787 remote keyless entry		Multi
		433.920	4330E, 4332E, 4333E	
	4335E			Multi, Four
<b>COSTEL</b>	300.000	Minitix		Multi
<b>CPS</b>	433.920	TCP3, CPS, Jolly 4		Multi, Four
		CPS1 TCP3, CPS2 TCP3, CPS4 TCP3 EM1CV, EM2CV, EM4CV		Multi, Four
<b>DASPI</b>	433.920	Daspi Happy2 433, Daspi Pops2		Multi, Four
		Daspi Zero2, Zero2CLO, Zero4CLO		Multi, Four
<b>DEA</b>	306.000	306 1, 306 2, 306 4		Multi
		306		Multi
	433.920	433 1, 433 2, 433 4, Gold S1, Gold S2 Dea Gold 238 S1, Dea Gold 238 S2, Dea Gold 239 S4		Multi, Four
		Genie		Multi, Four
		Punto S2		Multi, Four
		Dea MIO TD2, MIO TD4		Multi, Four
<b>DELMA</b>	300.000	Apollo 300, ELSAMEC Apollo 300		Multi
		Mizard 300 1, Mizard 300 2, King		Multi
	433.920	Mizard 433 1, Mizard 433 2		Multi, Four

		King 433 2		Multi, Four
		Style Copy 2CH (this is a code duplicator)		Multi, Four
<b>DICKERT</b>	433.920	MAHS433 01, MAHS433 04 <b>Note: we can NOT guarantee that it can be duplicated, because it depends by the receiver.</b>		Multi, Four
		S10-433A1L00, S10-433A4L00, S20-433A1L00, S20-433A4L00, S20-433A1000, S20-433A4000 <b>Note: only RED buttons model can be duplicated!</b>		Multi, Four
		S5-433-A2L00, S5U-433-A2L00 <b>Note: only RED buttons model can be duplicated!</b>		Multi, Four
	868.350	HS868-21 <b>Note: only RED buttons model can be duplicated!</b>		Multi
		S5-868A2L00, S5U-868A2L00 <b>Note: only RED buttons model can be duplicated!</b>		Multi
		S10-868A100, S10-868A400, S20-868A1L00, S20-868A4L00, S20-868A1000, S20-868A4000 <b>Note: only RED buttons model can be duplicated!</b>		Multi
<b>DIGICODE</b>	300.000 310.000	DC5010, DC5012, DC5030, DC5032, DC5040, DC5042, DC5060, DC5062, DC5070, DC5072		Multi
<b>DITEC</b>	433.920	GOL4C		Multi, Four
		GOL4 <b>Note: These transmitters are rolling code and cannot be duplicated, but if you have a GOL4C device, you can duplicate it on Four or Multi, and it works with all the DITEC receivers.</b>		Multi, Four
		BIX LS2, BIX LP2, BIX LG4 <b>Note: These transmitters are rolling code and cannot be duplicated, but if you have a GOL4C device, you can duplicate it on Four or Multi, and it works with all the DITEC receivers.</b>		Multi, Four
<b>DOITRAND FDOITRAND</b>	433.920	MPSTF2E JAUNE, MPSTF4E, HYPERPHONE MPSTF2E_GRISE		Multi, Four





































		TS2DE, TS4DE		Multi, Four
<b>DOORHAN</b>	433.920			Multi, Four
<b>DOORMATIC</b>	433.920	SAW		Multi, Four
<b>DUCATI ALLDUCKS</b>	433.920	TSAW1, TSAW2, TSAW3, TSAW4, 124 ELBER TSAW1, TSAW2, TSAW3, TSAW4 RONDY TSAW1, RONDY TSAW2, RONDY TSAW3		Multi, Four
		TPR10-A, TPR20-A RONDY TPR10_A, RONDY TPR20_A		Multi, Four
		TE2		Multi, Four
		HC6203, 6203: only blue with transparent buttons, and transparent with transparent buttons		Multi, Four
<b>ECP</b>	292.000	FIX 292 MHz F105611		Multi
		KEY 292 MHz F106038		Multi
<b>ELBE</b>	433.920	501, 502, 504		Multi, Four
		502a, 504a		Multi, Four
		502, 504		Multi, Four
<b>ELCA</b>	300.000	Aster 1100, Aster 1101		Multi
	433.920	IRIS, IRIS 9CH. Model 433D only! Both colors red and blue		Multi, Four
		ASTER2		Multi, Four
		Aster 1000, Aster1001. Model 433D only! Colors: black, blue, light grey		Multi, Four
		GEMINI 9CH		Multi, Four
		VIRGO		Multi, Four

<b>ELEK</b>	300.000	KTM194B		Multi
		KTR4		Multi
<b>ELV CONRAD</b>	868.350	FS20 S4, FS20 S8, FS20 S8-2, FS20 S16, FS20S16R, FS20 S20-2, FS20 S20-3		Multi Rev.4
<b>ELVOX</b>	433.920	Elvox ET		Multi, Four
		Elvox ET03, ET04		Multi, Four
	868.350	Elvox ET08		Multi
<b>EMFA</b>	287.000	ET1, ET2, ET3		Multi
	308.000	ES_1, ES_2		Multi
<b>ERONE</b>	433.920	SETDS39433E2, SETDS39433E4		Multi, Four
<b>ERREKA</b>	289.000	Erreka E20, Erreka E22		Multi
	433.920	Erreka Luna, Erreka SMAT 1 RESON 1, RESON 2, RESON 3		Multi, Four
<b>EUROPE AUTOMATISMES</b>	306.000	ASMY1, ASMY2, ASMY4		Multi
	433.920	ARMY1, ARMY2, ARMY4		Multi, Four
		S1, S2, S3		Multi, Four
<b>FAAC</b>	300.000	TM300S, TM300S05 H Faac TM1 300, TM2 300, TM3 300		Multi
	315.000	T1, T2, T3 Faac TM1 315, TM2 315, TM3 315		Multi
	330.000	TM1, TM2, TM3 Faac TM1 330, TM2 330, TM3 330		Multi
	418.000	TM1 418 DS, TM2 418 DS, TM3 418 DS		Multi
		TM1 418SL, TM1 418SL, TM2 418 SL, TM3 418SL		Multi



	433.920	TM1 433 DS, TM2 433 DS, TM3 433 DS TM1 433DS DPH, TM2 433DS DPH, TM3 433DS DPH		Multi, Four
		TML2 433 SLR, TML4 433 SLR, TML2- 433-SLR, TML4-433-SLR, TML2 433 ESL, TML4 433 ESL		Multi, Four
		TML2 433 SLP, TML4 433 SLP, TML2- 433-SLP, TML4-433-SLP		Multi, Four
	868.350	TM1 868 DS, TM2 868 DS, TM3 868 DS TM1 868DS DPH, TM2 868DS DPH, TM3 868DS DPH		Multi
<b>FADINI BPT</b>	315.000	ASTRO75-1, ASTRO75-2, ASTRO75-4		Multi
	433.920	433 2M, Astro43_2m		Multi, Four
		Astro433-2, Astro433-4, Astro43-2, Astro43-4		Multi, Four
<b>FERPORT</b>	433.920	Tac1, Tac2, Tac4, Tac1k, Tac2k, Tac4k, Tac2kr		Multi, Four
<b>FUNKMODUL ELSECO</b>	433.920	T433A2K1, T433A2K2		Multi, Four
		T433A2K4, T433A2K4n		Multi, Four
<b>GIBIDI</b>	306.000	TS2M		Multi
	433.920	Open TMB 433, OPEN TMQ 433, OPEN OUT 2, OPEN OUT 4		Multi, Four
<b>GOBBATO</b>	306.000	T306		Multi
<b>GRIFFON</b>	403.55	Griffon 404 MHz dip switch remotes and duplicating remotes		Multi
	433.92	Griffon 433 MHz dip switch remotes and duplicating remotes		Multi, Four
<b>GTO</b>	318.000	GTO Mighty Mule 1/2 buttons, RB741, RB742		Multi
		GTO Mighty Mule 3 buttons, RB743		Multi
<b>GULLIVER</b>	306.000	MDRQ 306		Multi
	433.920	MDW 2E		Multi, Four

<b>HAUSS</b>	433.920	Pocket 3750-1, Pocket3750-2, Pocket 3750-4		Multi, Four
<b>HEDDOF</b>	318.000	P219-1, P219-2		Multi
		P220-1, P220-2, P220-3		Multi
<b>HORMANN HOERMANN</b>	433.920	HSM2, HSM4, yellow buttons  <b>Please note that, in Netherlands, Hoermann sell this kind of remote control which transmit a rolling code: in this case it cannot be duplicated!</b>		Multi, Four
		HS1, HS2, HS4, blue buttons		Multi
	868.300	HSD2		Multi
		HSE2, HSE4, blue buttons		Multi
		HSM2, HSM4, blue buttons		Multi
		HSP4, blue buttons		Multi
		HSS2, HSS4, blue buttons		Multi
		HSZ1-868, HSZ2-868		Multi
<b>HRC</b>	433.920			Multi, Four
<b>JAY</b>	433.920	UBEI x1 SL1		Multi, Four
		UBET 11, UBET 21, UBET 31, UBET 41, UBET 61Å,		Multi, Four
<b>JCM</b>	290.000	EC1, EC2, EC3, ET1, ET2, ET3		Multi
<b>KEY AUTOMATION</b>	433.920	900TXB-42, 900TXB-42N, 900TXP-42, 900TXP-42N		Multi, Four
		900TXB-44, 900TXG-44		Multi, Four
		900SUB-44, 900SUB-44N, 900SUB-44W, 900SUB-44WN		Multi, Four



















		900TXK-42, 900TXW-42,900TXK-44, 900TXW-44		Multi, Four
<b>KING</b>	433.920	<b>Note: <a href="#">receiver</a> should be setup with rolling code feature disabled</b>		Multi, Four
<b>LABEL IUPPITER</b>	306.000	MDR, IUPPITER 306		Multi
	433.920	RJW/1E, RJW/2E, RJW/4E, RJW/12E		Multi, Four
		MDW/1E, MDW/2E		Multi, Four
<b>LEB</b>	306.000	TSA4		Multi
	433.920	TMW		Multi, Four
		TSAW2N, TSAW4N		Multi, Four
		TCP3Ã, (this is a code duplicator)		Multi, Four
		TRK4 <b>Note: <a href="#">receiver</a> should be configured to disable rolling check.</b>		Multi, Four
		TPW4		Multi, Four
	868.300	TPK4		Multi
<b>LINCE</b>	302.000	LE TX1, LE TX2		Multi
	433.920	LR 2035		Multi, Four
<b>LINEAR</b>	300.000 310.000	MULTI-CODE 308911, 308913, 1089		Multi
		MULTI-CODE 412001, 414001, 109410, 109710		Multi
		MULTICODE 306010, 307010, 108210		Multi
		MULTI-CODE 308301, 308302		Multi
		MULTI-CODE 105015		Multi
	310.000	Delta3 Moore-o-Matic: DT, DT2, DT2A, DT22A, DTC, DTD		Multi

		Delta 3 Moore-o-Matic: DT3, DT4		Multi
		Delta 3 Moore-o-Matic: Mini-T LB "LadyBug"		Multi
	312.000	Delta3 DTK (canada)		Multi
<b>MA SYSTEM</b>	433.920	MA TX1, MA TX2, MA TX3		Multi, Four
<b>MARANTEC</b>	418.000	D212, D222, D232		Multi
	433.920	D101		Multi, Four
		D12		Multi, Four
		D212, D222, D232		Multi, Four
		Digital 302, D302		Multi Rev.4, Four Rev.4
		Digital 304, D304		Multi Rev.4, Four Rev.4
		868.300	Digital 302, D302	
	Digital 304, D304			Multi Rev.4 Rev.4
<b>MCZ</b>	433.920	Aster		Multi, Four
<b>MEIßNER MEISSNER</b>	433.920	LW433-1, LW433-2, LW433-4		Multi, Four
		Pocket 3750 1, 2, 4		Multi, Four
<b>MONSEIGNEUR</b>	433.920	ARC2, ARC4		Multi, Four
		TDR 400 3845, TDR 400 3846, TDR 400 3847 T1SAW433, T2SAW433, T4SAW433		Multi, Four
<b>MOTORLINE STATEUROP</b>	433.920	MX1, MX2, MX3, MX4, MX6 MX11, MX12, MX13		Multi, Four
<b>MOTOSTAR</b>	433.920	CLIKSTAR2, CLICKSTAR4 CLICK-4M, CLICKSTAR RE 532, CLICKSTAR RE 534		Multi, Four

<b>NICE</b>	306.000	EASY S1, S2, S4		Multi
	433.920	FLO1, FLO2, FLO4		Multi, Four
		VERY VE		Multi, Four
<b>NOLOGO</b>	306.000			Multi
	433.920	ECO DIP		Multi, Four
<b>NOVOTECNICA</b>	306.000	BIT N1, BIT N2		Multi
		BIT NT1, BIT NT2, BIT NT4		Multi
<b>OG</b>	433.920	OG62, OG64		Multi, Four
<b>O&amp;O OeO, O and O</b>	306.000	O and O TX02		Multi
	433.920	OeO T-COM DS 4-2, O&O T-COM DS 4-4		Multi, Four
<b>OPENOUT</b>	306.000	TS2M		Multi
	433.920	TMQ 433 2, TMQ 433 4		Multi, Four
<b>PIAZZETTA</b>	433.920	4 buttons for wood/pellet heater		Multi, Four
<b>PORTAMATIC</b>	433.920	MPH01, MPH02		Multi, Four
<b>POWERFIX Profi (Lidl)</b>	433.920	RCB-A 3600R		Multi, Four
<b>PRASTEL</b>	306.000	NCSMT1, NCSMT2P, NCSMT4P		Multi
		KMFT2P, KMFT4P, KMFT2P93, KMFT4P93		Multi
	433.920	MPSTF2E, MPSTF4E		Multi, Four
<b>PROEM</b>	433.920	ER2C4ACM, ER4C4ACM		Multi, Four
<b>PROGET</b>	433.920	ETY_433N2, ETY 433N4		Multi, Four





















		EMI433-N2		Multi, Four
<b>PROTECO</b>	433.920	TX433		Multi, Four
		EUROMATIC		Multi, Four
		HIT		Multi, Four
<b>PUJOL</b>	288.000	JCM TRINARIO 1, TRINARIO 2, TRINARIO 3		Multi
	288.000	TT1, TT2, TRINARIO 1, TRINARIO 2		Multi
<b>PULSAR</b>	318.000	9931-318, 9931T-318		Multi
<b>QUASAR</b>	287.000	Tx SA4, Serie Argento, SA		Multi
	287.000	TXSA2T		Multi
	306.000	300 2, 300 4		Multi
	433.920	433 TANGO SLIM BLEU		Multi, Four
<b>QUICK</b>	433.92	Model: 302		Multi
<b>RADIODIGIT</b>	291.000	TBM, TCM		Multi
<b>ROGER</b>	433.920	R80/TX12, R80/TX14, R80/TX12R, R80/TX14R		Multi, Four
		H80/TX22		
		G80/TX32, G80/TX34, G80/TX32R, G80/TX34R		
<b>SEA</b>	433.920			Multi, Four
		SMART433_TX2_DIP, SMART433_TX3_DIP, SMART433_TX2_COPY, SMART433_TX3_COPY, Smart2 Dip Switch, Smart3 Dip Switch		Multi, Four
	868.350	231103, SEA868_4		Multi
		231103, Head2 Dip Switch		Multi















		SMART868-TX2-DIP, SMART868-TX3-DIP Smart2 Dip Switch, Smart3 Dip Switch		Multi
<b>SEAV</b>	306/330	TX1, TX2, TX3, TX4, TX1/330 TX2/330, TX3/330, TX4/330		Multi
	433.920	TXS1, TXS2, TXS3, TXS4		Multi, Four
		Behappy S1, Behappy S2, Behappy S3		Multi, Four
		Be Easy TX, Be Easy Murale2		Multi, Four
		BeSmart S2, BeSmart S4		Multi, Four
		BeFree S1		Multi, Four
	868.300	BeSmart H2, BeSmart H4		Multi
		BeFree H1		Multi
<b>SECURVERA</b>	433.920	SV R2C		Multi, Four
		SV R2C		Multi, Four
		SV R4C		Multi, Four
		SV R6C		Multi, Four
<b>SENDER</b>	433.920			Multi, Four
<b>SENTRY MARTIN ELECTRONICS</b>	403.550	SENTRY binary, SENTRY trinary		Multi
	433.920	SENTRY binary		Multi, Four
<b>SERAI</b>	310.000	OG/32		Multi
	433.920	OG/52, OG/54, OG/82, OG/84		Multi, Four
		OG/28, OG/48, OG/62, OG/64		Multi, Four
		OG/02, OG/04		Multi, Four





<b>SICE</b>	433.920	TX4 CLACK Bigfoot		Multi, Four
<b>SILVELOX - INTRA</b>	306.000	Green case with black buttons		Multi
	433.920	Silvelox Intra HSM4		Multi, Four
<b>SIMBA</b>	433.920	Simba RC1		Multi, Four
<b>SIMINOR</b>	433.920	ER2C4ACM, ER4C4ACM, ER2C4ACS, ER4C4ACS		Multi, Four
<b>SKYLINK</b>	300.000 310.000	MultiLink SD300M, Skylink 100, LD310M, SD310M		Multi
	318.000	Skylink Mtilink PD-318M		Multi
	390.000	Multilink CB-390M, CD-390M (versions compatible with Chamberlain)		Multi
<b>SMD</b>	433.920	LW433-1, LW433-2, LW433-4 : AM models only		Multi, Four
<b>SOMFY</b>	433.920	LEB TMW		Multi, Four
<b>SPARKRITE</b>	?	SRA2-2		Multi
<b>STAGNOLI</b>	433.920	ZEUS AZTR		Multi, Four
	868.350	ZEUS AZTR		Multi
<b>STANLEY</b>	310.000	24286		Multi
		1082		Multi
		1050		Multi
		1094		Multi
		1097		Multi

<b>STARTEC</b>	433.920	TXQ2		Multi, Four
<b>STINGER</b>	300.000 310.000 318.000 390.000	300MCD21V, 300MCD22V 310MCD21V, 310LID21V, 310LID22V 318ALD31V 390LMD21V, 390LMPB1V	 diff. colors	Multi
<b>TAU</b>	315.000	250 TXA2, 250 TXA4		Multi
	433.920	250 SLIM, 250K-SLIM, 250K-SLIMC		Multi, Four
		250TXD2, 250TXD4		Multi, Four
		250BUG2, 250BUG4		Multi, Four
		250T-4, 250T-4C		Multi, Four
<b>TEC KEY</b>	300.000	MK1010		Multi
<b>TECNOMATIC</b>	433.920	TQ433		Multi, Four
<b>TEDSEN BERNER GFA Elektromaten</b>	433.920	SKX1MD, SKX2MD, SKX3MD, SKX4MD		Multi, Four
		SKX1KD, SKX2KD, SKX4KD, SKX6KD		Multi, Four
		SKX1DL, SKX2DL, SKX3DL, SKX4DL		Multi, Four
		SKX1LC, SKX2LC, SKX3LC, SKX4LC		Multi, Four
		SKX1SL, SKX2SL, SKX3SL, SKX4SL		Multi, Four
		SKJ		Multi, Four
		SKX1WD, SKX2WD, SKX4WD, SKX11WD, SKX22WD, SKX44WD		Multi, Four
<b>TELCOMA</b>	306.000	RCS TP2		Multi Rev.4
		RCST2, RCST4		Multi Rev.4
	433.920	Telcoma EDGE 2, Telcoma EDGE 4		Multi, Four
		TANGO 2 SW, TANGO4 SW	 	Multi, Four

		TANGO BLUE 2, TANGO 4 BLUE, TANGO BLEU 2, TANGO BLEU 4		Multi, Four
		TANGO 2 N, TANGO 4 N		Multi, Four
		TANGO 2 SLIM, TANGO 4 SLIM		Multi, Four
		Telcoma Noire2, Noire4 <b>Note: Rolling-code jumper should be removed from the receiver!</b>		Multi, Four
		TANGO WIN3		Multi, Four
		TANGO2, TANGO4		Multi, Four
<b>TELEMATIC</b>	300.000	TL1, TL2		Multi
<b>TKC</b>	433.920	TSAW433		Multi, Four
<b>TONKARR</b>	287.000	TK2		Multi
<b>TORAG</b>	433.920	S429 1, S429 2, S429 4		Multi, Four
<b>TORMATIC DORMA</b>	433.920	HS, Dorma HS43 1E, HS43 2E, HS43 3E, HS43 4E		Multi, Four
		MAHS, Siebau, Novoferm, Dorma		Multi, Four
		MHS, MHS43-1		Multi, Four
<b>TREMA</b>	433.920	TO93TV1, TO93TV2, TO93TV4		Multi, Four
<b>TUBAUTO</b>	433.920	DIGITAL 101 433		Multi, Four
<b>V2</b>	306.000	TRR1_306		Multi
	318.000	TPS1K		Multi
	433.920	PHOENIX series: Phoenix2, Phoenix2P, Phoenix4, Phoenix4P, TXC2 Contr.47, TXC4 Contr.47, Handy2 Contr.47, Handy4 Contr.47, TRC4 Contr.47, TSC4 Contr.47 . <b>Note:the receiver should be programmed with the rolling code</b>		Multi, Four



		<p><b>feature disabled.</b> When the code is learned, LED will blink for 6 times to highlight that the code is rolling.</p>		
		TCP3		Multi, Four
		TCP3, ARC3		Multi, Four
		TCP3		Multi, Four
		TPR		Multi, Four
		T1SAW/433, T2SAW/433, T4SAW/433		Multi, Four
		TRR1, TRR2, TRR4		Multi, Four
		PMR2, PMR4		Multi, Four
	868.300	<p>PHOENIX series: Phoenix2-868, Phoenix2P-868, Phoenix4-868, Phoenix4P-868.</p> <p><b>Note:the receiver should be programmed with the rolling code feature disabled.</b> When the code is learned, LED will blink for 6 times to highlight that the code is rolling.</p>		Multi
VISONIC	315.000	WT100, WT100A, WT101, WT101A, WT102, WT104, WT-201, WT-201A, WT-201WP, WT-201AWP		Multi
	418.000	WT-100, WT-100A, WT-101, WT-101A, WT-102, WT-104, WT-201, WT-201A, WT-201WP, WT-201AWP		Multi
	433.920	WT 100, WT 100A, WT 101, WT 101A, WT 102, WT 104, WT 201, WT 201A, WT 201WP, WT 201AWP		Multi, Four
VSEG	433.920	CR SLIM		Multi, Four
VISA ELECTRONICS	306.000	VISA VRK 4021A		Multi
	433.920	Visa Beet 1, Visa Skippy		Multi
WAINE-DALTON	433.920	S429-1, S429-2, S429-4, S429-mini		Multi, Four

		S425		Multi, Four
<b>WECLA CDS</b>	433.920	433, 433_2		Multi, Four
<b>ZULLAN</b>	315.000	250TXA1H, 250TXA2H, 250TXA4H		Multi
<b>OEM</b>	315.000			Multi

### **Incompatible remote controls**

Our products MULTI and FOUR cannot duplicate remote controls which transmits below 286 MHz (for example 27, 30, 40 MHz remote controls). The following table lists some remote controls that are known to be not compatible.

<i>Company</i>	<i>Frequency</i>	<i>Models</i>	<i>Photo</i>	<i>Notes</i>
<b>ALLMATIC</b>	433.920	TECH3, BRO	Several different enclosures	Rolling code
<b>APERTO</b>	434.420	TX02-434-2		Rolling code
<b>AVIDSEN</b>	433.920	TOV		Rolling code
<b>B&amp;D</b>	433.920	062170/4333EBD 1A4982		10 trinary
<b>BFT</b>	433.920	MITTO2, MITTO4		Rolling code
<b>CARDIN</b>	433.920	S435		Rolling code
		S438, S449		FM / FSK
	868.300	S486		FM / FSK
<b>CHAMBERLAIN LIFTMASTER MOTORLIFT SEARS CRAFTSMAN</b>	433.920	84335eml, 94335e		Rolling code
<b>DICKERT</b>	433.920 868.300	S5-433-A2K00, S5U-433-A2K00, S10-433A1K00, S10-433A4K00, S20- 433A1K00, S20-433A4K00, HS868-50 roltek, S5-868A2K00, S5U- 868A2K00, S10-868A1K00, S10-868A4K00, S20- 868A1K00, S20-868A4K00		Rolling code
<b>DUCATI ALLDUCKS</b>	433.920	6203/R, 6203/P, 6204	Several different enclosures	Rolling code
<b>EAZYMATIC</b>	218.000			218 MHz
<b>FAAC</b>	868.300	TML2868SLH		Rolling code

		XT2868SLH, XT4868SLH		Rolling code
<b>FADINI</b>	868.350	BIRIO		Rolling code, programmed by palm
<b>GENIUS CASALI</b>	868.350	AMIGO JA332, AMIGO JA334		Rolling code
<b>GLIDEROL</b>	868.350	TM-868C		Rolling code (KeeLoq)
<b>HORMANN HOERMANN</b>	29-40MHz	Models with green or grey buttons		Cannot be duplicated
	433.920	RS2-433, RS4-433 (Rolling code versions, usually sold in Netherlands)		Rolling code (KeeLoq)
<b>MHOUSE</b>	433.920	TX3, TX4		Rolling code
<b>NICE</b>	30-40	BT1K, BT2K, BT4K, K1M, K2M, K4M	Several different enclosures	30-40MHz
	433.920	SMILO SM2, SM4		Rolling code
		FLO1R-S, FLO2R-S, FLO4R-S		Rolling code
<b>NORMSTAHL CRAWFORD</b>	433.920	EA433		Rolling code
<b>NOVOFERM</b>	433.920	MNHS433, NOVOTRON 502,504		Rolling code
<b>PROEM / SIMINOR</b>	433.920	ER2C4ACM, ER4C4ACM, ER2C4ACS, ER4C4ACS		Rolling code
<b>PRASTEL</b>	433.920	MPSTP2E, MPSDT2E, MT2E, MT4E,		Rolling code
<b>PUJOL</b>	433.920	P215/4, VARIO		Rolling code
<b>RIB</b>	312.000	312A		
	433.920	433		
<b>SKYLINK</b>	433.920	R3 serie		Rolling code
<b>SOMFY</b>	433.420	Keytis NS 2 RTS, Keytis NS 4 RTS		Rolling code
<b>SOMMER</b>	868.800	TX03 868 04		Rolling code
<b>TELECO</b>	433.920	TXP, TXR, TXV, TXW, TVT series		Rolling code
<b>TELE RADIO</b>	433 - 868	Tele radio T60 series		FM
<b>WELLER</b>	868.500	MT87A, MT87A4		Rolling code